

QUICK GUIDE FOR PIZZA WARMING OVEN

➔ **READ THIS ENTIRELY BEFORE YOU START THE WARMER!** ➔

This warmer is property of BHS Boosters and should not be removed from BHS Concessions without consent. Use is at your own risk. Do not leave unit unattended while in use.

-BEFORE HEATING- You must check the water pan located on the bottom floor of the warmer **every time you use the warmer.** To do this, remove the trays from the unit. If the water tray is less than 1/2 full of water, add cold water to equal about 3/4 full. **DO NOT OVER FILL THE TRAY!**

-Water can be left in the tray only if you are within your sport's season and will be using it again for Concessions. If this is a one-time use, please remove the water after use and dry water pan. If this is mid-season, you can remove the water completely at the end of the season and thoroughly clean the water tray before storing for next sport's use.

-All the controls for the warmer are located at the front bottom of the warmer under the door. Plug the red/black cord into the outlet above the counter. Turn **POWER** button on. Make sure the other button is on **HEAT** (never PROOF). Preheat to 185* (Ideal temperature for pizza slices, hot dogs or hamburgers is 165-170*).



-Humidity level should be maintained at a low-mid moisture range to prevent food from drying out or becoming too soggy (4-6). Check food and adjust as needed.

-As soon as you finish serving food, **turn off the POWER button** on warmer and **UNPLUG WARMER!**

-Allow it to cool while you clean the Concessions area. Wipe out the inside of the warmer, including the trays, once it is cool. USE NONABRASIVE, food safe cleaning products. Remove water if you will not be using again during your season. If you removed any trays for use, replace trays for storage.

(Questions? See Athletic Director to contact Main Boosters Executive Board)